



Xpress II Stair Lift

Inclined Platform Lift For Straight Stairways

Technical Information

Specifications

Standard Platform Sizes	800mm x 1250mm (31 1/2" x 49 1/4")
	800mm x 1000mm (31 1/2" x 39 3/8")
	750mm x 900mm (29 1/2" x 35 1/2")
Optional Platform Sizes	675mm x 1000mm (26 1/2" x 39 3/8")
	725mm x 1000mm (28 1/2" x 39 3/8")
Rated Load	250 kg (550 lbs)
Speed	Up: 4m (13 ft) per minute Down: 4.9 m (16 ft.) per minute
Operating Controls	Continuous pressure switches, 24 VDC.
Drive System Motor	0.75 H.P.
Power Requirements	208-240 VAC, 50/60 HZ single phase on a dedicated (North America = 20 amp, International = 15 amp) circuit.
Power Transmission	Rack & pinion
Emergency Use	A handwheel is provided. Auxiliary power system available.
Rail System	Champagne anodized aluminum extrusion with integrally mounted zinc plated gear rack.
Overspeed Safety	Mechanical overspeed sensor and lock, with electrical drive cut-out protection.
Xpress Delivery Time	Standardized components allow for fast delivery times.

Features

Features

Standard

- 800 x 1250mm ADA compliant platform
- Choice of three standard platform sizes
- Passenger grab rail
- Under platform obstruction sensing plate and bi-directional ramp sensors
- Emergency manual lowering and folding system
- Ready lamp safety indicator
- Power-fold platform and ramps
- Keyed Call Stations
- Keyless platform for easier operation
- Large illuminated platform directional buttons and an emergency stop button
- Powered platform safety arms
- 2 year warranty

Optional

- Auxiliary power system
- Fold down seat with seat belt
- Side-load platform for installations with confined lower landings
- Keyed platform operation for added security
- Vandal resistant platform lock (electric)
- Attendant remote control
- Narrow platform sizes
- Platform folds automatically if left unattended at landing to keep stairways clear
- Optional RAL colors
- Pedestrian audio visual alert
- Building fire alarm integration
- Outdoor cover (vinyl)
- Extended warranty (5 additional years) *USA/Canada only

Benefits




The optional fold-down ambulatory seat and seat belt allows a person with limited mobility to comfortably operate the Xpress II.




Garaventa Lift

18920 36th Avenue · Surrey, BC · V3Z 0P6 · Canada
T 604 594 0422 · T 800 663 6556 (toll free North America)
E info@garaventlift.com · I www.garaventlift.com



Authorized Garaventa Lift Representative

© Garaventa Lift. As we are continuously improving our products, specifications outlined in this brochure are subject to change without notice.

 Printed in Canada
15801-S-PB-EN